

Convex Poster Signholder

Applicable Products:

VX1

1. Attach upright to base using two flat head screws provided (fig. A).
2. Mount graphic unit onto upright using two flat head screws provided (fig. B).
3. Insert graphic into left upright channel (fig. C-1). Then, tuck graphic gently into right upright channel to complete installation (fig. C-2).

