

# SignPost System™ - Graphic Rod - CRGR and Costumer Arm - CRUM Series

1. Bottom Arm - Slide knob rest glide and foot of bottom costumer arm bracket into upright channel. Move to desired location and tighten knob rest to secure.
2. Top Arm - Slide knob rest glide and foot of top costumer arm bracket into upright channel. Move to desired location and tighten knob rest to secure.
3. Slide graphic over top and bottom costumer arms. Screw finishing pucks onto costumer arms to complete assembly

